


ETP Multiplier
Model AF140

- Connections:
A - Signal lead
B - not used
C - neg. kV
D - GND

Be sure to remove protective cover at top



A - use this lead

B - clip this lead

D

C

*Note that there are two signals leads:
use A and cut B where indicated*